

# Scott® Liberty I Standard Breathing Air System Trailer

## *Specially adapted for desert environments*

Totally enclosed single-axle trailer designed for mobile, on-scene filling applications is capable of being towed by any vehicle rated for 6000 lb. (surge brakes and 2-15/16" ball included). Designed specifically for deployable forces; U.S. Marine Corps preferred.

### Features

- RevolveAir® charge station
- Two ASME 6000psi storage cylinders
- Scott X4™ Controller with CO and moisture monitor
- Desert filters on engine and air intake remove fine sand particles
- Automatic control and indicator panel
- Auto drain system with muffler reservoir
- Stage gauge panel
- Emergency stop button
- Operation time meter
- 7.2kW generator
- Air-driven light tower with four 300w lights
- HP/Voltage/Phase/Hz: 20/460/3/60
- Color: desert sand



### More About...

#### Revolveair® Charge Station

Allows users to simultaneously charge two SCBAs within the protective chamber, while exchanging two more SCBAs on the outside of the chamber. Unit comes complete with safety interlocks and gauges, charge and bleed valves, and pressure regulator.



#### Scott X4™ Controller

Monitors and controls compressor's operations to ensure that clean, breathable air is delivered to each cylinder.

- Monitors discharge air temperature and oil level
- Measures CO and/or dew point for maximum output; shuts unit down to ensure acceptable air quality
- Measures and alarms for high CO and dew point levels
- Low oil and high temperature alarm
- Alerts for service and collects usage data



### Certification

Meets NFPA, NIOSH and CSA standards.

### Warranty

One year on entire unit; two year on compressor block.

Description	Fisher Catalog No.
Scott Liberty I Compressor	19-110-130

## Fisher Safety Sales Representatives

**Mike Odom**  
(USN/USMC/USCG)  
619-931-8880  
[michael.odom@thermofisher.com](mailto:michael.odom@thermofisher.com)

**Steve Lowell**  
(USN/USCG/USAF/USA)  
813-494-1472  
[steven.lowell@thermofisher.com](mailto:steven.lowell@thermofisher.com)

**Ruth Meredith**  
(Fed. Gov't./USA/USMC/USN)  
813-494-5849  
[ruth.meredith@thermofisher.com](mailto:ruth.meredith@thermofisher.com)

**Scott Carpenter**  
(USN/USCG/USA)  
757-535-0576  
[scott.j.carpenter@thermofisher.com](mailto:scott.j.carpenter@thermofisher.com)

**Bob Wynn**  
(USAF/USA)  
702-813-8212  
[bob.wynn@thermofisher.com](mailto:bob.wynn@thermofisher.com)

**Rodney Born**  
(OK/TX)  
210-836-7480  
[rodney.born@thermofisher.com](mailto:rodney.born@thermofisher.com)